



Figure 1. Physical Photo of AHVA1KV7A

FEATURES

High Efficiency

High Output Current: 7A

High Output Voltage Stability

Linear Modulation of Output Voltage

Wide Range of Capacitance Load: 2 μ F to 20 μ F

Over-current and Short Circuit Protections

Displays for Output Voltage and Current

Low Cost

APPLICATIONS

Driving piezos or other high voltage high current loads.

DESCRIPTION

AHVA1KV7A is a bench-top high voltage amplifier/piezo driver for amplifying an analog input voltage into a high voltage high current output. AHVA1KV7A has a built-in high

voltage high current AC–DC converter which converts the 240VAC input voltage into an output voltage adjustable from 0 to 1kVDC.

SAFETY PRECAUTIONS

To ensure the safety for using the high voltage amplifier, make sure that the input voltage value falls within the value range required, 220VAC to 240VAC, and the maximum current allowed is $\geq 40A$. All the connection harnesses must have sufficient current capacity and enough voltage insulation rating. Keep a distance of at least 1.2 ft (30cm) away from other objects or walls to provide sufficient cool air for the internal ventilation fan.



SPECIFICATIONS

Table 1. Characteristics.

T_A = 25°C, unless otherwise noted

Parameter	Value	Unit/Note
Mains Voltage	230 ±10 % @ 50/60 Hz	VAC
Output Voltage Range	0~1000	V
Max. Output Current	7	A
Input Modulation Voltage	0~10	V
Input Resistance	1	MΩ
Full Load Efficiency	≥86%	
Operating Temperature	-10~45	°C
Digital Display	Output voltage display accuracy: 0.1%; Output current display accuracy: 1%	
Ripple Noise	≤2%	
Temperature Coefficient	<0.4 × 10 ⁻⁴ °C (preheating for 30 min)	
Protection Temp. for Overheat	70~80	°C
High Voltage Output Port	D-Sub 5W1 connector	
External Control Port	BNC	
Dimensions	430 × 550 × 220	mm
Weight	25/55	kg/lbs

DIMENSIONS



Figure 2. Dimensions of AHVA1KV7A



PANEL INSTRUCTIONS

Front panel




Figure 3. Front Panel

- 1. Power switch: ON and OFF indicate that the power is on and off respectively;
- 2. Display current: Display the actual current value;
- 3. Display voltage: Display the actual voltage value;
- 4. Offset: Turn the switch to adjust the output voltage;
- 5. OUT: The D-Sub 5W1 plug is the voltage output of the amplifier. The output voltage ranges from 0V to +1000 V; This is the [connector \(part #: 681M5W1203LYYY\)](#) used for the output, the pin locations in Figure 4; the cable [connector \(part #: 680M5W1103L201\)](#) can be used for mating with the output connector.




Figure 4. Pin Assignments for the Output Connector 5W1

- 6. D-Sub.
- 7. USB.
- 8. MON: Monitor output. Monitor the output voltage by a multimeter or an oscilloscope. The ratio of monitored voltage and output voltage is 1:100. The output signal ranges from 0V to +10V. The voltage can be set remotely when using both MOD and MON.
- 9. MOD: Modulation input. A 0 ~ 10V external input control voltage will be amplified to an output voltage of 0 ~ 1000V.

Back Panel



Figure 5. Back Panel

- 10. Input connector: A connector with 230VAC, 50/60Hz and up to 40A current.

Note: The plug on our piezo driver is NEMA 10-50.

NAMING INSTRUCTIONS




Figure 6. Naming Rules of AHVA1KV7A



ORDERING INFORMATION

Table 2. Unit Price

Quantity (pcs)	1 – 5	6 – 10	11 – 19	≥20
AHVA1KV7A	\$9600	\$9500	\$9400	\$9300

NOTICE

- ATI warrants performance of its products for one year to the specifications applicable at the time of sale, except for those being damaged by excessive abuse. Products found not meeting the specifications within one year from the date of sale can be exchanged free of charge.
- ATI reserves the right to make changes to its products or to discontinue any product or service without notice, and advise customers to obtain the latest version of relevant information to verify, before placing orders, that information being relied on is current and complete.
- All products are sold subject to the terms and conditions of sale supplied at the time of order acknowledgment, including those pertaining to warranty, patent infringement, and limitation of liability. Testing and other quality control techniques are utilized to the extent ATI deems necessary to support this warranty. Specific testing of all parameters of each device is not necessarily performed, except those mandated by government requirements.
- Customers are responsible for their applications using ATI components. In order to minimize risks associated with the customers' applications, adequate design and operating safeguards must be provided by the customers to minimize inherent or procedural hazards. ATI assumes no liability for applications assistance or customer product design.
- ATI does not warrant or represent that any license, either express or implied, is granted under any patent right, copyright, mask work right, or other intellectual property right of ATI covering or relating to any combination, machine, or process in which such products or services might be or are used. ATI's publication of information regarding any third party's products or services does not constitute ATI's approval, warranty or endorsement thereof.
- IP (Intellectual Property) Ownership: ATI retains the ownership of full rights for special technologies and/or techniques embedded in its products, the designs for mechanics, optics, plus all modifications, improvements, and inventions made by ATI for its products and/or projects.